

HCS-40 / Optional Accessories



19520 Manual Valve Package

Eliminates quick coupled hose changes between nut runner and torquing cylinder.



980 Low Torque Monitor

Attaches to nut runner to read very low torques accurately.



19516 Telescopic Drip Pans

Provides drip pan between bench and extended headstock.



906-25 Universal Ball Joint Chuck Adapter

Used to mount piston rods terminating in a female ball joint to the servicer T-slot chuck.



908/#907-25 Blank Chuck Adapters

For mounting fork lift and other cylinder flanges to servicer headstocks.



#909 V-Block Chuck Wings


For mounting cylinders in servicer chucks when the cylinder or rod does not have a pin bushing.



Square Drive Socket Adapters

Adapters provide the means of attaching conventional sockets to the headstock chucks.

(Available in 3/4", 1", 1 1/2", and 2 1/2")



#965 Extra Large Universal Wrench

Extra large Universal High Torque Wrench attaches to hex piston retaining nuts requiring 25,000 ft. lbs. or torque or less. Fits nuts 4" to 6 1/2" across flats.



#918 Off-Set Chuck Wings

For mounting wide cylinder eyes to servicer headstock chuck